

Handoff Document STEM Outreach  
CS410 Capstone Project  
3/19/2025  
Alea Minar

|  |          |
|--|----------|
| <b>Repository Overview</b>                 | <b>3</b> |
| Code                                       | 3        |
| arduino                                    | 3        |
| digital_twin                               | 3        |
| Documents                                  | 3        |
| images                                     | 3        |
| weekly_update_slides                       | 4        |
| Models                                     | 4        |
| blend_files                                | 4        |
| glb_files_for_ppt                          | 4        |
| stl_files                                  | 4        |
| Turntable, 18cm, marble bearings - 2763216 | 4        |
| <b>Installation and User Instructions</b>  | <b>5</b> |
| Model Setup                                | 5        |
| Arduino Setup                              | 5        |
| How to Run The Application                 | 7        |
| Testing                                    | 7        |
| Running the Application                    | 7        |

# Repository Overview

## Code

Contains all of the code required for installation and use of the application

### arduino

- detect\_magnet.ino
  - Uses hall effect sensor to determine if a magnet is detected and convert to rpm for digital twin match.
- magnet\_test.ino
  - Uses hall effect sensor to test if a magnet is detected.

### digital\_twin

- dt\_match.py
  - The main application. Can be used to run the digital twin connected to an arduino or used with a simulated port.
- dt\_turbine.py
  - Uses VTK to display and rotate the models at an rpm specified by user input.
- simulate\_rpm.py
  - Used to simulate a serial port and randomly generate rpm.
- dynamic\_base.stl
  - Model of the rotating part of the digital twin (generator, shaft, gear, and turbine).
- static\_base.stl
  - Model of the stationary part of the digital twin (the base that supports the model).

## Documents

Contains documentation associated with the project.

### images

- 3D\_prints
  - Images of what has been 3D printed for this project.
- diagrams
  - Diagrams of hydroelectric components.
- measurements

- Images of Nick's model with associated measurements.
- models
  - Images of the 3D models designed for this project.

### weekly\_update\_slides

The slideshows from (semi) weekly updates on the project.

## Models

### blend\_files

- Contains the blend files for all of the models designed for this project

### glb\_files\_for\_ppt

- Contains glb files of some models used for powerpoints.

### stl\_files



- Contains stl files of models that were either printed or used for visualization

### Turntable, 18cm, marble bearings - 2763216

- Turntable sourced from Thingiverse user Zippitybamba, and is licensed under Creative Commons


# Installation and User Instructions

## Model Setup

| Model name   | Model Image  | Printed Image  | Dimensions (X-Y-Z)                      | Layer height |
|--|--|--|---|--------------|
| generator_support_yoke   |   |   | 127-127-57.2 mm                         | 0.24mm       |
| The generator slides onto the shaft and will need to be secured to the turntable (hot glue would be acceptable). |  |  |   |              |
| magnetic_pole_v1   |  |  | 215.9(8.5")-215.9 (8.5")-63.5 mm (2.5") | 0.2mm        |
| The magnetic pole slides into place on the generator.  |  |  |   |              |

## Arduino Setup

### 1. Breadboard diagram



- Connect VCC to 5V
- Connect GND to GND
- Connect DAT to pin 2
- Insert 10k resistor in front of the Hall Effect Sensor VCC and DAT

**Note** that the Hall Effect Sensor must be quite close to the neodymium magnets.

## 2. Attach neodymium magnets

- Each prong of the gear should have a neodymium magnet attached (currently set to 8 prongs, if the number of prongs changes, change “magnetsPerRevolution” in code/arduino/detect\_magnet/detect\_magnet.ino accordingly).
- **NOTE** that the direction of the magnet **MATTERS**. When setting it up, upload code/arduino/magnet\_test/magnet\_test.ino onto the arduino.

## 3. Attach arduino and breadboard

- You may either utilize a bluetooth arduino or a corded one (as I did). Ensure that the device you are using to run the application has a serial port (or use a bluetooth arduino).
- You may wish to permanently attach the arduino to the base, in which case hot glue is safe to (carefully) use. Otherwise, you may consider using a rubber band.

- The arduino can be attached anywhere on the base, but for convenience I attached mine near the breadboard on the underside of the cross beam.
- Attach the mini breadboard (mine came with a sticky back) to the underside of the cross beam, carefully lining it up so the **Hall Effect Sensor is as close as possible to the neodymium magnets.**

## How to Run The Application

### Testing

#### Test if magnets are detected

- open code/arduino/magnet\_test/magnet\_test.ino in the Arduino IDE (ver. 2.3.4)
- Upload magnet\_test.ino to the arduino
- Hold magnets near the Hall Effect Sensor, “Magnet detected!” will be printed if a magnet is detected and “No magnet detected.” otherwise.

#### Test if Python application is working

- Download socat (virtual serial port)  
`brew install socat`
- Run socat with  
`socat -d -d pty,raw,echo=0 pty,raw,echo=0`
- Running socat will print two ports. Enter the first port (e.g. ttys003) into code/digital\_twin/dt\_match.py “SERIAL\_PORT”. Enter the second port (e.g. ttys004) into code.digital\_twin/simulate\_rpm.py “SIMULATED\_PORT”.
- In a separate terminal, run simulate\_rpm.py  
`python simulate_rpm.py`
- In a 3rd terminal, run dt\_match.py  
`python dt_match.py`

dt\_match.py will read the randomly generated rpms from the socat serial port and display the model rotating using VTK.

### Running the Application

- Change the port as necessary
  - code/digital\_twin/dt\_match.py “SERIAL\_PORT”
  - You can see a list of available serial ports with  
`ls /dev/tty.*`
- Run dt\_match.py  
`python dt_match.py`